

GEOTEXTILE CORNERS PREFORMED WATERPROOFING MEMBRANE CORNERS



PRODUCT DESCRIPTION

Ready to use preformed corners for use in combination with HBS-200® and SMP-300® coatings. For reliable and watertight sealing under slabs, ceramic floors and tiles. The corners have a length of 11cm and a sealing width of 6cm.

FIELD OF APPLICATION

Suitable for waterproofing bathroom flooring, (walk-in) showers, shower walls, bathtub walls. Perfect for waterproofing overlapping areas and to be used in combination with HBS-200® Liquid Rubber and SMP-300® Polymer coating. Easy to install in a corner and avoid time-consuming job sitecutting.

PROPERTIES

- · Ready to use corners
- · Elastic
- Excellent absorption of HBS-200® Liquid Rubber and SMP-300® coatings.
- · Strong
- · Non-woven

APPLICATION

Directions for use:

Before using HBS-200® Liquid Rubber or SMP-300® Polymer coating, stir manually until a homogenous colour is obtained. It is not recommended to use an electric mixer with a high rotational speed for stirring. GRIFFON GeoTextile corners must be applied in still wet HBS-200® Liquid Rubber or SMP-300® Polymer coating. Then immediately level off with a second layer. Always ensure a layer thickness of at least 2 mm after curing.

Our advice is based on extensive research and practical experience. However, in view of the large variety of materials and the conditions under which our products are applied, we assume no responsibility for the results obtained and/or any damage caused by the use of the product. Nevertheless, our Service Department is always at your disposal for any advice needed.